

How to configure AlphaTECH IP BOLD 65 Intercom on Wildix PBX

For network settings and mounting guide, refer to:

http://www.alphatechtechnologies.cz/soubory_edit/Ke_stazeni_auto/EN/Manuals/IP-BOLD65-quick-setup-v1.2.pdf

Setup user on Wildix PBX

Create a new user

Edit ✕

User User

User Name

Login

Phone

Fax

Office

Email

Mobility

Dialplan users (Internal dialplan)

Fax dialplan users (Internal dialplan)

Language En

Group Default

Department

Clic on "Set Password" to set SIP/VoIP password

	User Name	Login	Phone	Fax	Office	Email	Mobility	Dialplan	Fax dialp...	Group	Department	PBX
	Door Phone		199					users	users	Default		suppor...

Set passwords ✕

WEB ●

SIP/VoIP ●

Setup IP BOLD

SIP parameters

ALPHATECH TECHNOLOGIES s.r.o.  **ALPHA**
Tech

IP BOLD

SIP parameters

SIP mode: SIP server

Display name: VoIP Guard

Account: 199

Auth. Id: 199

Password:

Send register:

Registration server: 192.168.133.14

Port: 5060

Expiration [sec]: 600

Registrate after restart:

SIP server: 192.168.133.14

Port: 5060

Outbound proxy:

Port: 5060

SIP Transport: UDP

Provisional code: 180 Ringing


Enable Symmetric RTP:

Registration successful

Default values Save

SIP mode : SIP server
Account : 199 (internal number configured in PBX)
Auth.Id. : 199 (as internal number)
Password : SIP/VOIP password set in user config of PBX, i.e. **wa2ogly#nf**
Registration server : IP address of PBX
SIP server : IP address of PBX
SIP Transport : UDP (usually)

Basic settings

ALPHATECH TECHNOLOGIES s.r.o.  **ALPHA**
Tech

IP BOLD

Number: **1**

Phonebook

Title:

Email:

Enabled:

1. call number:

Timetable:

Calling:

2. call number:

Timetable:

Calling:

3. call number:

Timetable:

Calling:

4. call number:

Timetable:

Calling:

5. call number:

Timetable:

Calling:

External code for relay 1:

External code for relay 2:

External code for relay 3:

External code for relay 4:

Navigation Sidebar:

- Current status
- Network setting
- Basic settings
 - Phonebook**
 - Relay
 - Door sensors
 - Setting SNMP
 - Timetable
 - Time setting
 - E-mail
- Extended settings
- Service
- Video camera

1...5 call number: configure a single or sequence of numbers to distribute call to several numbers.

Note: If **WP600A**, **iOS** or **Android** device, video starts automatically!